

# Sanoca Fire Department

## Mobile Vehicular Repeater

### Receive Radio

(Driver Side)

### Transmit Radio

(Passenger Side)

Ch1:153.980 136.5pl →→→→→→→→→→→→→→→→Ch1:154.980 136.5pl

Ch2:154.980 136.5pl →→→→→→→→→→→→→→→→Ch2:154.980 136.5pl

Ch3:154.280 192.8pl →→→→→→→→→→→→→→→→Ch3:153.980 136.5pl

Ch4:154.280 CSQ →→→→→→→→→→→→→→→→Ch4:153.980 136.5pl

---

Ch 1 & 1 are used for instances where the County repeater goes down. This will repeat portables to Rural Fire “Talk-Around” only. You can talk to Wilson, if Wilson is on the “back-up radio”.

Ch2 & 2 **\*\*DO NOT USE\*\*** (\*\*locks up county repeater\*\*)

Ch 3 & 3 is used to repeat portables that are not copied by Wilson 911. If talking on a portable and Wilson cannot hear you, switch portable to Ch3 “Mobile Repeater”.

Ch 4 & 4 is used for multi-jurisdictional responses to Wilson County. This channel set on repeater allows for communications interoperability by all field units switching to “State Fire”. Transmitting on “State Fire” allows unit to talk to Wilson on Wilson Rural Fire. However, unit will not receive Wilson Rural Fire.